

Spiral Rack

ASSEMBLY INSTRUCTIONS

PART LIST

- 1-Circle shelf
- 1-TOP TUBE
- 1-UNDER TUBE
- 1-BASE
- 2-TOP BOLTS
- 2-Prop up poleS
- 2-UNDER BOLTS
- 2-capS
- 29-Ball bearingS

BOLTS ARE SCREWED
IN PLACE

